



KINGA FLOOR LAMP

These instructions are provided for your safety. Please read carefully before commencing work and retain for future reference.


SAFETY INFORMATION

- * If the flexible cable of this product is damaged it should be exclusively replaced by the manufacturer or a similar qualified person in order to avoid a hazard.
- * To prevent electrocution switch off at the mains supply before assembling or maintaining this fitting. Ensure the plug is not connected to any power supply and read instruction before assembly.
- * This fitting is fitted with a 3 Amp fuse and is suitable for 240 Volt ring mains.
- * Always be sure to use the correct type and wattage of bulbs as indicated on the fitting. Never exceed the wattage stated.
- * When changing the bulb, ensure product is unplugged and allow the old bulb to cool down before handling. Dispose of used bulbs carefully.

ASSEMBLY INSTRUCTIONS

- 1. Unpack the product and remove all packaging. Be careful not to scratch the surface of the product whilst removing the plastic wrapping.
- 2. Lay the product out on the floor. If the floor is not carpeted please cover it with a soft cloth to avoid damage to the flooring and surface of the product. Assembly should take place with the product lying flat.
- 3. It may be necessary to remove protective packaging (plastic / cardboard) located at cable entry points of the product.
- 4. Offer the base plate, ① base weight onto the end of the main stem ② and ensure screw holes ③ are aligned before using 2 x screws provided to secure these parts together. ④ Take care not to trap the cable in the process.
- 5. Peel off the protective cover on base felt then attach base felt to the underside of the floor lamp base whilst making sure this is located centrally. (5)
- 6. Pull excess cable out of the lower part of stem until the top lamp holder stem touches lower stem, this should be fully located into position, you may need to undo the hex screws fitted into the stem
 6. Use the hex key provided 7 to lightly secure the stem into position. 8 (DO NOT FULLY TIGHTEN HEX SCREWS)
- 7. Stand the floor lamp upright whist making sure the base and lamp horizontal stem are aligned then use hex key to fully the hex screws.

 Take care not to overtighten the hex screws.
- 8. Remove shade ring from the lamp holder then fit the shade (9) and secure this using the shade ring. (10)
- 9. **Fit bulb**, type and wattage as indicated on fitting. **The wattage** indicated must not be exceeded.
- 10. Your floor lamp is now ready for use.



GENERAL INFORMATION

This floor lamp is designed for internal use only. **Do not use polish or an abrasive cleaner - just a soft dry cloth.**